

# Colorex

# MÄSTAR



## Product description:

Mästar is a rich, semi-matt/semi-glossy/glossy, water based enamel paint with high coverage. It is suitable for all kind of carpentry indoors, for instance door frames, trims, furniture etc. Suitable foundation is primed wood and chipboard. As prime coat, use Snickerigrund Aqua, which is to be used on earlier, not treated wood. Mästar enamel is in accordance with highest demands on gloss, resistance and hardness. Easy to apply with excellent adhesion, minimum of visible brush strokes and is non-yellowing. On doors or similar big surfaces Mästar can be applied with roller or can be sprayed after diluting with 5-10% water.

Mästar is produced in Sweden and is included in Colorex Mix tinting system.

## TECHNICAL DATA:

Area of application	Indoors
Binder	Acrylic
Volume Solids	40%
Density	1,29 g/cm <sup>3</sup>
Viscosity	280
Gloss	40 semi glossy
Washability	Yes. > 10 000 cycles
Thinner/Cleaning	Water
Material consumption	6–10 m <sup>2</sup> /L
Temperature at painting	Minimum +5°C
Tools for painting	Brush, enamel-roller and (after dilution) spray
Dust dry	1–2 h
Re-paintable	12 h
Completely dry	72–96 h
Colour	White
Flammability	Not flammable
VOC category	(Cat A/d): 130 g/l (2010)

# Colorex

# MÄSTAR



## How to use

### Pre-painting

Always start by reading the instructions on the tin. It is important to be thorough from the beginning. The use of correct tools and a carefully performed base is the foundation for a successful result. Stir the paint properly from the bottom of the tin before starting painting. Protect floor and furniture properly before starting to paint. Apply under controlled conditions, where air-, paint- and surface temperature may not be below +5°C. High humidity will prolong the drying time. The substrate which shall be painted shall be clean, with good adhesion, dry and dust free. Wash, flush and remove old paint with bad adhesion. Glossy surfaces shall be sanded matte. Uneven surfaces shall be treated with putty, sanded and wiped clean before priming with Snickerigrund Aqua.

### Painting

The paint is ready to use. Apply with brush or suitable enamel roller. After light diluting with water, it can also be applied by spraying. Smoothen with enamel brush. When applying tinted paint, try to apply complete areas with paint from the same paint container. Recommended are two layers, depending on type and colour of surface which shall be painted. Risen humidity will prolong the open time of the product which simplifies work over larger surfaces.

### Post-painting

Wipe off the tools thoroughly before cleaning in water and a mild cleaning liquid. Seal the tin carefully after use and keep out of reach for children. Liquid residues may not be poured down the drain, but be submitted to the local collection point.

### Maintenance

Use a damp cloth and possibly some mild detergent to clean the surface. Never use spirits by cleaning painted or lacquered surfaces.